



Agilis and Protero (Interior & Exterior) Cleaning & Maintenance Guidelines

Storage & Handling

- Do not store or install near an exposed flame, source of heat, or source of ignition.
- Store in a dry, interior space. Clean gloves must be used to avoid fingerprints. When removed for install, store in a flat, horizontal position.

Powder coat paint finish

Cleaning

For Agilis and Protero products with a powder coat paint finish the following cleaning method can be used.

- Using a clean damp cloth or soft, smooth sponge with a mild, clear detergent, wipe lightly on the surface to remove any dirt.
- Dry any excess moisture with a clean, white microfiber cloth. Note: If moisture is not removed, it may stain the surface over time.
- Please consult the manufacturer's instructions and guidance regarding any cleaning product.

Dust Removal

A commercial vacuum system with 100-inches/H2O vacuum capacity is recommended for removing dust particles. The vacuum system cleaning attachment should be a 3" diameter wand with natural hair bristle. A HEPA vacuum filter is recommended to minimize airborne dust during the cleaning process. Care must be taken while vacuuming to avoid excessive pressure.

Laminate 'Wrap' Finish

Cleaning

- For cleaning use proper neutral detergent, dehydrated ethanol, or other alcohol-based agents. Remember to thoroughly remove these agents with water after cleaning.
- Avoid using any strong alkaline and/or acid-based detergents, thinner or other organic solvents.
- For cleaning use a soft cloth. Never attempt to use a sponge or other tool containing abrasives.

